



***** Not supplied with all models. If not supplied, skip step 11

1

Step 4 **x8**

Step 14 **x4**

***** **x1**

Step 11 **x4**

x4

x2

Bin & tray will vary between models

Supplied components

2

L R

Use above template to mark holes

3

x8

2.5mm

Drill marked holes

4

x8

4.5mm

Attach both brackets

5

Align bottom of bracket with top of runner to measure location of mounting holes

6

Mount runner as per manufacturers instructions

7

Mount door to runners

8

Remove drawer assembly

9

Install drawer back

10

Re-install drawer assembly and adjust door

11

x4

x4

x2

Attach door brackets if supplied

12

Install tray

13

x4

2.5mm

Center tray, mark and drill holes

14

x4

4.5mm

Attach tray with stepped screws

15

Re-install drawer and insert metal lid

16

Insert bins in tray